


Comfortable wireless neck speaker with microphone, powered by Alango's advanced audio technology. Delivers high quality crisp sound from any Bluetooth®-enabled source: television\*, cell phone, computer, music player, gaming device, etc., while leaving your ears free. Extractable earbuds enable private listening.




## Key Benefits

- ▶ Brings sound close to your ears for a personal, immersive experience
- ▶ Pairs simultaneously and switches easily between TV and smartphone
- ▶ Supports low-latency aptX, enabling perfect audio-video synchronization with no lip sync issues
- ▶ Loud and clear mobile calls, podcasts, streamed videos, and video conferences
- ▶ EasyListen™ slows down incoming cell phone speech for better comprehension
- ▶ SonicVibrance™ provides stereo sound enhancement
- ▶ Suitable for use with hearing aids
- ▶ Also works as tabletop speaker

## Functional Diagram



- 1 - Volume up
- 2 - Multifunction button
- 3 - Volume down
- 4 - Loudspeakers (left & right)
- 5 - Notification LED (left & right)
- 6 - Microphone
- 7 - Left retract button



- 8 - Right retract button
- 9 - Micro USB charging port
- 10 - Power ON/OFF switch
- 11 - Mode switch
- 12 - Extractable earphones (left & right)
- 13 - Silicone earbuds (left & right)
- 14 - Serial number label

\*If your TV doesn't support Bluetooth®, use our BeHear LINK audio transmitter to make the connection.

## Electrical Specifications

### Bluetooth

- **Bluetooth compliance:**  
Bluetooth v.4.2 + EDR + Low Energy
- **Supported Bluetooth profiles:**  
HFP v1.6, HSP v1.2, A2DP v1.2
- **Bluetooth transmission power:** Class II, +4dBm
- **Operating range:** 10m (~33 ft)
- **Paired devices:** Supports two simultaneous connections (multi-point)

### Audio

#### Loudspeakers

- **Frequency range:** 20Hz – 20kHz
- **Sensitivity:** 102dB ± 3dB @ 1mW

#### Earphones

- **Frequency range:** 20Hz – 20kHz
- **Sensitivity:** 102dB ± 3dB @ 1mW

#### Microphone

- **Type:** Omni-directional MEMS
- **Frequency range:** 50Hz – 10kHz

## Battery

- **Battery capacity:** 1050mAh
- **Operation Time:**
  - **Personal sound amplification:** up to 50 hours
  - **Calls (via earphones):** up to 45 hours
  - **Media play (via earphones):** up to 40 hours
  - **Media play (via loudspeakers):** up to 10 hours
- **Standby time:** ≥ 1300 hours
- **Charging time:** ~3 hours
- **Charging interface:** micro-USB

## Mechanical Specifications

- **Wearing style:** Around the neck
- **Weight:** 256g (9 oz.)

## Certifications



*Specifications are subject to change without prior notice.*

## Package Contents



Neck speaker



Silicone ear buds  
in varying sizes



Micro USB  
charging cable



Quick start  
guide

