



Safety Data Sheet

Page 1 of 7

LOCTITE 401 INSTANT ADHESIVE known as Loctite 401
INSTANT ADH 500ML

SDS No. : 427627
V001.3
Date of issue: 02.04.2020

Section 1. Identification of the substance/preparation and of the company/undertaking

Product name: LOCTITE 401 INSTANT ADHESIVE known as Loctite 401 INSTANT ADH 500ML

Intended use: Cyanoacrylate

Supplier:

Henkel Australia Pty Ltd
135-141 Canterbury Road
Kilsyth, Victoria, 3137
Australia

Phone: +61 (3) 9724 6444

Emergency information: 24 HOUR EMERGENCY CONTACT NUMBER: 1800 032 379

Section 2. Hazards identification

Classification of the substance or mixture

Hazardous according to the criteria of Safe Work Australia.

GHS Classification:

Hazard Class

Flammable liquids

Skin irritation

Serious eye irritation

Target Organ Systemic Toxicant -

Single exposure

Hazard Category

Category 4

Category 2

Category 2A

Category 3

Target organ

respiratory tract irritation

Hazard pictogram:



Signal word:

Warning

Hazard statement(s):	H227 Combustible liquid. H315 Causes skin irritation. H319 Causes serious eye irritation. H335 May cause respiratory irritation.
Precautionary Statement(s):	
Prevention:	P210 Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. P261 Avoid breathing dust/fume/gas/mist/vapours/spray. P264 Wash hands thoroughly after handling. P271 Use only outdoors or in a well-ventilated area. P280 Wear protective gloves/eye protection.
Response:	P302+P352 IF ON SKIN: Wash with plenty of water. P304+P340+P312 IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. Call a POISON CENTER or physician if you feel unwell. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P332+P313 If skin irritation occurs: Get medical advice/attention. P337+P313 If eye irritation persists: Get medical advice/attention. P362 Take off contaminated clothing. P370+P378 In case of fire: Use water spray (fog), foam, dry chemical or carbon dioxide to extinguish.
Storage:	P403+P233 Store in a well-ventilated place. Keep container tightly closed. P405 Store locked up.
Disposal:	P501 Dispose of contents/container to an appropriate treatment and disposal facility in accordance with applicable laws and regulations, and product characteristics at time of disposal.

Dangerous Goods information:

Not classified as Dangerous Goods according to the criteria of the Australian Code for the Transport of Dangerous Goods by Road and Rail (ADG Code).

Section 3. Composition / information on ingredients

General chemical description: Mixture
Type of preparation: Cyanoacrylate Adhesive

Identity of ingredients:

Chemical ingredients	CAS-No.	Proportion
Ethyl 2-cyanoacrylate	7085-85-0	60- <= 100 %
non hazardous ingredients~		< 10 %

Section 4. First aid measures

Ingestion:	Ensure that breathing passages are not obstructed. The product will polymerise immediately in the mouth making it almost impossible to swallow. Saliva will slowly separate the solidified product from the mouth (several hours).
Skin:	<p>If lips are accidentally stuck together apply warm water to the lips and encourage maximum wetting and pressure from saliva inside the mouth.</p> <p>Peel or roll lips apart. Do not try to pull the lips apart with direct opposing action. Do not pull bonded skin apart. It may be gently peeled apart using a blunt object such as a spoon, preferably after soaking in warm soapy water.</p> <p>Cyanoacrylates give off heat on solidification. In rare cases a large drop will generate enough heat to cause a burn.</p> <p>Burns should be treated normally after the adhesive has been removed from the skin.</p>
Eyes:	<p>If the eye is bonded closed, release eyelashes with warm water by covering with wet pad. Cyanoacrylate will bond to eye protein and will cause periods of weeping which will help to debond the adhesive.</p> <p>Keep eye covered until debonding is complete, usually within 1-3 days.</p> <p>Do not force eye open. Medical advice should be sought in case solid particles of cyanoacrylate trapped behind the eyelid cause any abrasive damage.</p>
Inhalation:	Move to fresh air, consult doctor if complaint persists.
First Aid facilities:	Eye wash Normal washroom facilities
Medical attention and special treatment:	<p>Treat symptomatically.</p> <p>Surgery is not necessary to separate accidentally bonded tissues. Experience has shown that bonded tissues are best treated by passive, non-surgical first aid. If rapid curing has caused thermal burns they should be treated symptomatically after adhesive is removed.</p>

Section 5. Fire fighting measures

Suitable extinguishing media:	Foam, dry chemical or carbon dioxide.
Improper extinguishing media:	High pressure waterjet
Decomposition products in case of fire:	Upon decomposition, this product emits carbon monoxide, carbon dioxide and/or low molecular weight hydrocarbons.
Special protective equipment for fire-fighters:	Wear self-contained breathing apparatus and full protective clothing, such as turn-out gear.

Section 6. Accidental release measures

Personal precautions:	<p>See advice in section 8</p> <p>Avoid contact with skin and eyes.</p> <p>Wear protective equipment.</p>
Environmental precautions:	Do not empty into drains / surface water / ground water.
Clean-up methods:	Do not use cloths for mopping up. Flood with water to complete polymerization and scrape off the floor. Cured material can be disposed of as non-hazardous waste.

Section 7. Handling and storage

Precautions for safe handling:	Use only in well-ventilated areas. Use personal protective equipment as described in Section 8. Avoid contact with fabric or paper goods. Contact with these materials may cause rapid polymerization which can generate smoke and strong irritating vapors, and cause thermal burns. Use of dispensing equipment is recommended to minimise the risk of skin or eye contact
Conditions for safe storage:	Store in a cool, dry, well-ventilated area. For optimum shelf life store in original containers under refrigerated conditions at 2 - 8°C (35.6 - 46.4 °F) Keep away from heat and direct sunlight. Keep container tightly sealed.

Section 8. Exposure controls / personal protection

National exposure standards:

None

Engineering controls:

General room ventilation is usually adequate.
Provide local ventilation for prolonged use in a confined area.

Eye protection:

Safety goggles or safety glasses with side shields.

Skin protection:

Protective clothing that covers arms and legs.
Please note that in practice the working life of chemical resistant gloves may be considerably reduced as a result of many influencing factors (e.g. temperature). Suitable risk assessment should be carried out by the end user. If signs of wear and tear are noticed then the gloves should be replaced.
Chemical resistant, impermeable gloves.

Use nitrile gloves and aprons as necessary to prevent contact. Do not use PVC, nylon or cotton.

Respiratory protection:

If inhalation risk exists, wear a respirator or air supplied mask complying with the requirements of AS/NZS 1715 and AS/NZS 1716.

Section 9. Physical and chemical properties

Appearance:	colourless to yellowish Liquid
Odor:	Sharp
Flash point:	80 - 93 °C (176 - 199.4 °F)
Density:	1.1 g/cm3

Section 10. Stability and reactivity

Stability:	Stable under normal conditions of temperature and pressure.
Conditions to avoid:	Extremes of temperature. Polymerizes on contact with moisture.

Incompatible materials: Rapid exothermic polymerization will occur in the presence of water, amines, alkalis and alcohols.

Hazardous decomposition products: In case of fire toxic gases can be released.
carbon oxides.

Section 11. Toxicological information

Health Effects:

Ingestion: Not expected to be harmful by ingestion. Rapidly polymerizes (solidifies) and bonds in mouth. It is almost impossible to swallow.

Skin: Cyanoacrylates have been reported to cause allergic reaction but due to rapid polymerization at the skin surface, an allergic response is rare.
Causes skin irritation.
Bonds skin in seconds.

Cyanoacrylates generate heat on solidification. In rare circumstances a large drop will burn the skin. Cured adhesive does not present a health hazard even if bonded to the skin.

Eyes: Irritating to eyes. Causes excessive tearing. Eyelids may bond.

Inhalation: Exposure to vapors above the established exposure limit results in respiratory irritation, which may lead to difficulty in breathing and tightness in the chest.

Aggravated med. condition: Pre-existing skin, eye and respiratory allergies.

Acute toxicity:

Hazardous components CAS-No.	Value type	Value	Route of application	Exposure time	Species	Method
Ethyl 2-cyanoacrylate 7085-85-0	LD50	> 5,000 mg/kg	oral		rat rabbit	OECD Guideline 401 (Acute Oral Toxicity) OECD Guideline 402 (Acute Dermal Toxicity)
	LD50	> 2,000 mg/kg	dermal			

Skin corrosion/irritation:

Hazardous components CAS-No.	Result	Exposure time	Species	Method
Ethyl 2-cyanoacrylate 7085-85-0	slightly irritating	24 h	rabbit	OECD Guideline 404 (Acute Dermal Irritation / Corrosion)

Serious eye damage/irritation:

Hazardous components CAS-No.	Result	Exposure time	Species	Method
Ethyl 2-cyanoacrylate 7085-85-0	irritating	72 h	rabbit	OECD Guideline 405 (Acute Eye Irritation / Corrosion)

Respiratory or skin sensitization:

Hazardous components CAS-No.	Result	Test type	Species	Method
Ethyl 2-cyanoacrylate 7085-85-0	not sensitising		guinea pig	not specified

Germ cell mutagenicity:

Hazardous components CAS-No.	Result	Type of study/ Route of administration	Metabolic activation / Exposure time	Species	Method
Ethyl 2-cyanoacrylate 7085-85-0	negative negative negative	bacterial reverse mutation assay (e.g Ames test) mammalian cell gene mutation assay in vitro mammalian chromosome aberration test	with and without with and without		OECD Guideline 471 (Bacterial Reverse Mutation Assay) OECD Guideline 476 (In vitro Mammalian Cell Gene Mutation Test) OECD Guideline 473 (In vitro Mammalian Chromosome Aberration Test)

Section 12. Ecological information

General ecological information:

Do not empty into drains / surface water / ground water., Biodegradable product of low ecotoxicity.

Persistence and degradability:

Hazardous components CAS-No.	Result	Route of application	Degradability	Method
Ethyl 2-cyanoacrylate 7085-85-0	not readily biodegradable.	aerobic	57 %	OECD Guideline 301 D (Ready Biodegradability: Closed Bottle Test)

Bioaccumulative potential / Mobility in soil:

Hazardous components CAS-No.	LogPow	Bioconcentration factor (BCF)	Exposure time	Species	Temperature	Method
Ethyl 2-cyanoacrylate 7085-85-0	0.776				22 °C	EU Method A.8 (Partition Coefficient)

Section 13. Disposal considerations

Waste disposal of product:

Cured adhesive: Dispose of as water insoluble non-toxic solid chemical in authorised landfill or incinerate under controlled conditions.

Disposal for uncleaned package:

Packaging that cannot be cleaned are to be disposed of in the same manner as the product.

Section 14. Transport information

Road and Rail Transport:

Dangerous Goods information:

Not classified as Dangerous Goods according to the criteria of the Australian Code for the Transport of Dangerous Goods by Road and Rail (ADG Code).

Marine transport IMDG:

Not dangerous goods

Air transport IATA:

UN no.:	3334
Proper shipping name:	Aviation regulated liquid, n.o.s. (Cyanoacrylate ester)
Class or division:	9
Packing group:	III
Packing instructions (passenger)	964
Packing instructions (cargo)	964
Additional Information IATA:	Primary packs containing less than 500ml are unregulated by this mode of transport and may be shipped unrestricted.

Section 15. Regulatory information

SUSMP Poisons Schedule None

Section 16. Other information

Abbreviations/acronyms: ADGC - Australian Dangerous Goods Code
IMDG: International Maritime Dangerous Goods code
IATA-DGR: International Air Transport Association – Dangerous Goods Regulations

Reason for issue: Reviewed SDS. Reissued with new date. involved chapters: 1,2

Date of previous issue: 10.04.2015

Disclaimer:

The percentage weight (% w/w) of ingredients is not to be taken as a specification guaranteed by Henkel Australia Pty. Limited, but only as an approximate guide to the content of hazardous ingredients in the material. The information contained herein does not constitute a guarantee by Henkel Australia Pty. Limited concerning the properties of the material.

The information contained in the Safety Data Sheet is offered in good faith and has been developed from what is believed to be accurate and reliable sources. The information is offered without warranty, representation, inducement or licence and Henkel Australia Pty. Limited assumes no legal responsibility for reliance upon same. Henkel Australia Pty. Limited disclaims any liability for loss, injury or damage incurred in connection with the use of the material or its associated Safety Data Sheet.

This information is not to be construed as a representation that the material is suitable for any particular purpose or use except those conditions and warranties implied by either Commonwealth or State statutes. Customers are encouraged to make their own enquiries as to the material's characteristics and, where appropriate, to conduct their own tests in the specific context of the material's intended use.

No warranty or representation of any kind is given with respect to the substantive or export laws of any other jurisdiction or country. Please confirm that the information provided herein conforms to the substantive export or other law of any other jurisdiction prior to export. Please contact Henkel Product Safety and Regulatory Affairs for additional assistance.